

H4

OVERHANG

8d nails at 6" o.c.
staggered and
clinched

LPI Blocking*

4'-0" min

2 x 4 cut
to fit both
sides

2 x 4 filler

2'-0" max

* Lateral resistance shall be provided. Other methods of restraint, such as full depth LP SolidStart OSB Rim Board, LP SolidStart LVL, LP SolidStart LSL or metal X-bracing may be substituted for the LPI blocking shown.