

C8d

BRICK LEDGE CANTILEVER

Full Depth Reinforcing- Both Sides

23/32" APA Rated OSB or 1" (min) LP Rim Board reinforcing, both sides. 14" and deeper I-Joists also require web fillers both sides (see detail C7a). Nail or screw reinforcing with (3) 6d or 8d box nails or #6x 1-1/2" wood screws into both flanges. Use construction adhesive between all surfaces. (Note: Pilot holes required with screws)

