



BULLETIN

SUBJECT: *Touch-ups*

Date: *Revised 8MR10*
No.: *CanExel-1*

CanExel siding should be inspected when installation is completed. Check for nicks and chips from manipulation. A quick verification will identify minor spots to touch-up and is a proper way to ensure the siding was installed professionally, without noticeable faults.

If touch-ups are required, we suggest you follow the very easy method detailed in the photos below for quick correction (dip in paint lightly, dab, blot onto spots and repeat).

It is recommended that the touch up paint be applied with a cotton swab **Q-tip**. Apply the paint to the affected areas on the boards and let it dry for approximately 1 hour.

Do not apply with a paint brush

For best results, the exterior temperature should be at least 50°F/10°C (24 hour period)

